

Wireless USB Manager Windows 7 Beta Release Installation Guide

In order to get the most optimal performance of your Wireless USB products, please follow below instructions to install the Windows 7 Beta Release compatible driver and update the firmware of your USB Transmitter, Video Receiver and/or Audio Receiver. Before you begin, please make sure you log into the system as system administrator or have administrative access right to the system.

For Windows 7:

To install driver on your system:


1. Download the “**UWB_Gen3_Beta_112309**” zip file and extract the content to folder **UWB_Gen3_Beta_112309**. After the extraction is completed, there are two folders, Drivers and FWUpdate.
2. Double click on the Driver folder, and you will see two folders, 32-bit and 64-bit. Depending on the system configuration, you will need to use the setup file in different folder to install the correct driver. Right click on the **setup.exe** and select **Run as administrator** to begin the installation.
3. Follow the on-screen prompts to complete the installation. Restart your system when the installation completes.

For Windows 7:


To update firmware for USB Transmitter:

Note: The overall process may take few minutes to complete. During the firmware update process, please do not turn off your system or unplug the USB Transmitter from your system.

1. Keep your USB Transmitter plugged in, **DO NOT** take out your USB Transmitter.
2. In the UWB_Gen3_Beta_112309 folder, double click on FWUpdate folder and then double click on HWA folder.
3. Depends on your system configuration, select the correct folder that meets your system configuration, **32-bit** or **64-bit**, to continue. Right click on **HWAFUT.exe** and select **Run as administrator** to continue.
4. Scroll down to the bottom of the license agreement and click on **Next** to continue.



5. Click on **Next** to continue.



6. You will be prompted by a software installation security window. Click on **Install Anyway** to continue.
7. Click on **Next** to continue.



8. Click on **Finish** to complete the firmware update process for the USB Transmitter.




For Windows 7:

To update firmware for Video Receiver:

Note: The overall process may take few minutes to complete. During the firmware update process, please do not turn off your system, unplug the power adapter from the Video Receiver or remove the USB cable unless instructed to do so.


1. Keep the power adapter plugged in your Video Receiver, **DO NOT** remove the power adapter.
2. In the UWB_Gen3_Beta_112309 folder, double click on FWUpdate folder and then double click on wVGA folder.
3. Depends on your system configuration, select the correct folder that meets your system configuration, **32-bit** or **64-bit**, to continue. Right click on **FirmwareUpdateDS.exe** and select **Run as administrator** to continue.
4. Plug the mini-B connector of the USB cable into the Video Receiver, and USB type-A connector to your system. Click on **Next** to continue.




5. Click on **OK** to continue.




6. Click on **Next** to continue.



7. Click on **Finish** to continue and **DO NOT** power cycle your device at this step.



8. Click on **OK** to continue.



9. Now you can power cycle your Video Receiver by unplugging and plugging in the power adapter to the Video Receiver. Click on **OK** when the power cycle completes, and you can unplug the USB cable from your system to the Video Receiver.




For Windows 7:

To update firmware for Audio Receiver:

Note: The overall process may take few minutes to complete. During the firmware update process, please do not turn off your system, unplug the power adapter from the Audio Receiver or remove the USB cable unless instructed to do so.


1. Keep the power adapter plugged in your Audio Receiver, **DO NOT** remove the power adapter.
2. In the UWB_Gen3_Beta_112309 folder, double click on FWUpdate folder and then double click on wAudio folder.
3. Depends on your system configuration, select the correct folder that meets your system configuration, **32-bit** or **64-bit**, to continue. Right click on **FirmwareUpdateDS.exe** and select **Run as administrator** to continue.
4. Plug the mini-B connector of the USB cable into the Audio Receiver, and USB type-A connector to your system. Click on **Next** to continue.




5. Click on **OK** to continue.




6. Click on **Next** to continue.



7. Click on **Finish** to continue.



8. Click on **OK** to continue.



9. Now you can power cycle your Audio Receiver by unplugging and plugging in the power adapter to the Audio Receiver. Click on **OK** when the power cycle completes, and you can unplug the USB cable from your system to the Audio Receiver.

