

UNIVERSAL POWER PLUG ADAPTER QUICK INSTALL GUIDE

MODEL 100007

Thank you for purchasing the MANHATTAN® Universal Power Plug Adapter, Model 100007.

Safe, reliable and easy to use, its all-in-one design adapts plugs for use in most international power outlets, eliminating the annoyance of tangled cords and loose adapters that are easily lost when traveling.



Selector slides easily to the proper local setting (as shown on back of this sheet)

See reverse for Selector instructions

Safety switches lock the retractable plugs in place for use and travel

- Built-in over-temperature, overload, short-circuit and surge protection
- Rated to handle both 110- and 220–240-volt standards
- Lifetime Warranty

SPECIFICATIONS

Electrical

- Power rating: 15 A 125 VAC / 10 A 250 VAC (does not convert voltage)
- Surge protection: 150 Joules
- Max. clamping voltage: 775 V
- Max. spike: 6000 V / 4500 A

Standards & Certifications

- CE, EMC

Connections

- Europe, North & South America, Australia, U.K. power plugs (male)
- Universal power plug (female)

Physical

- Plastic housing
- LED surge indicator
- 8 x 4.5 x 4.0 cm (3 x 1.7 x 1.5 in.)
- 105 g (3.7 oz.)

Suitable for most consumer electronics. Does not reduce or convert electrical voltage; not recommended for use with high-wattage devices. Check device specs before use.


MANHATTAN
BRINGING COMPUTERS TO LIFE

MANHATTAN® offers a complete line of PC Components, Peripherals, Cables and Accessories. Ask your local computer dealer for more information or visit us online at

www.manhattan-products.com

Copyright © MANHATTAN

All products mentioned are trademarks or registered trademarks of their respective owners.


MH-100007-QIG-0809-01

To use the Universal Power Plug Adapter, you first need to set the adapter's plug to the proper setting for the region in which you are using the adapter. The adapter's safety feature then temporarily locks out the alternate plug settings.

To set the adapter, hold it with the center selection switch facing you so you can read the settings. Then, move the switch to the proper position for your region, as indicated by the diagrams below. After setting the adapter, you can plug it into an available power outlet and connect your device to the adapter.


North & South America (USA / AUS / NZ setting):

Slide the selector to the left, then move the safety switch on the right toward you so the UK/European plugs will be locked out by the safety feature.




Australia & New Zealand (USA / AUS / NZ setting):

Slide the selector to the left, then move the safety switch on the right toward you and swivel the pins so the UK/European plugs will be locked out by the safety feature.



United Kingdom (UK setting):

Slide the selector to the right, then move the safety switch on the left toward you so the US/European plugs will be locked out by the safety feature. Pull out the ground prong as shown.



Europe (EUROPE setting):

Slide the selector to the center, then rotate the plug out so the US/UK plugs will be locked out by the safety feature.

