

POWER ADAPTER REFERENCE GUIDE

MODEL 100854

Thank you for purchasing this MANHATTAN® Power Adapter, Model 100854.

This lightweight device lets you obtain the power you need for your notebook computer and most any other portable device. A complete list of notebook computer compatibility is on the back of this sheet and on the item's datasheet at www.manhattan-products.com.



- Convertible DC plug tips ensure proper polarization and fit
- Selectable voltage output levels match your device's requirements
- Overload, overheat and over-current protection help ensure reliable operation
- Lifetime Warranty

INSTRUCTIONS

1. Select the DC plug tip that fits into your portable device and connect it to the output cable of the power adapter.
2. With the proper DC plug tip in place, connect the power adapter to your portable device. (It's recommended that the portable device be turned off.)
3. Position the adapter's voltage switch to the appropriate setting.
4. Plug the adapter into an AC power outlet and check that the red LED is lit.
5. Read the Operating Cautions on the back of this sheet, then turn on the attached portable device.

SPECIFICATIONS

STANDARDS & CERTIFICATIONS

- FCC
- CE

GENERAL

- Input: 100–240 V; 47–63 Hz
- Output: 12–24 V; max. 4 A; 70 W

Voltage/current settings (max.):

- 12 V / 4 A
- 15 V / 4 A
- 16 V / 3.5 A
- 18 V / 3.5 A
- 19 V / 3.5 A
- 20 V / 3.5 A
- 24 V / 2.9 A

PHYSICAL

- Cable (combined length): 2.75 m (9 ft.)
- Dimensions: 58 x 36 x 115 mm (2.3 x 1.4 x 4.5 in.)
- Weight: 345.9 g (12.2 oz.)

PACKAGE CONTENTS

- Power Adapter
- 10 DC plug tips
- Reference guide



MANHATTAN® offers a complete line of PC Components, Peripherals, Cables and Accessories.

Ask your local computer dealer for more information or visit us online at

www.manhattan-products.com

Copyright © MANHATTAN

All products mentioned are trademarks or registered trademarks of their respective owners.

