NUMERIC KEYPAD USER MANUAL

MODEL 1763.54





INTRODUCTION

Thank you for purchasing the MANHATTAN® Numeric Keypad, Model 176354. With its convenient design, this device enhances any notebook computing experience, especially when inputting important numeric data.

The full-size 19-key layout and scissor-style (X-structure) key switch technology help reduce typing noise, improve response and provide low-profile keystrokes for fast and accurate data entry. The handy backspace key allows swift corrections, and the asynchronous number lock function keeps this mode independent of the computer's keyboard so you can simultaneously input letters from the comptuer's keyboard and input numeric data from the keypad.

Plus, as with all MANHATTAN devices, it comes with a Lifetime Warranty.

INSTALLATION/OPERATION

- 1. Plug the USB cable into the USB port on the computer.
- Activate the Number Lock function by pressing the "Num Lock" key. The LED will light. NOTE: The factory default is set with "Num Lock" activated.





- 3. When "Number Lock" is in use, the keys are defined as in Figure 1 below.
- 4. When "Number Lock" is in not use, the keys are defined as in Figure 2 below.

Num Lock	1	*	BkSp
7	8	9	-
4	5	6	+
1	2	3	Enter
0	00		

 Num Lock
 /
 *
 BkSp

 HOME
 ↑
 PgUp

 ←
 →
 +

 END
 √
 PgDn
 Enter

 INS
 Shift
 DEL
 Enter

Figure 1

Figure 2

SPECIFICATIONS

General

- Number Lock LED indicator
- · Windows 2000/XP/Vista compatible
- USB cable, 89 cm (35 in.)
- 11.4 x 8 x 1.2 cm (4.5 x 3.125 x 0.5 in.); 76.5 g (2.7 oz.)

Package Contents

- · Numeric Keypad, Asynchronous
- User manual





MANHATTAN® offers a complete line of PC Components, Peripherals, Cables and Accessories. Ask your local computer dealer for more information or visit us online at

www.manhattan-products.com